Installation Instructions

Contender Series Lazy Susans

Full Round Shelves

1. Locate base piece in corner cabinet to desired location with set screw pointing toward front and fasten to cabinet floor with provided screws. Install lower portion of telescoping rod into base piece and fasten by tightening set screw.
2. Install hub kits only lazy susan shelves.
3. Place lower lazy susan shelf over shaft into final position.
4. Place collar assembly ring with set screw over lower portion rod and tighten set screw in collar assembly ring at desired height.. Then lower the other lazy susan shelf(s) over the lower portion onto collar ring assembly.
5. Place upper portion of telescoping rod onto lower portion and place upper pivot plate onto upper rod portion. Extend upper rod portion and pivot plate up against cabinet cross member (or final location) and tighten set screw on telescoping rod. Fasten upper pivot plate to cross member.
6. Repeat step for twice for a three shelf susan.

Pie Cut Shelves

1. Locate base piece in corner cabinet to desired location with set screw pointing toward front and fasten to cabinet floor with provided screws. Install lower portion of telescoping rod into base piece and fasten by tightening set screw.
2. Install hub kits only lazy susan shelves.
3. Place lower lazy susan shelf over shaft into final position.
4. Place upper shelf base piece over lower portion rod with set screw pointed toward front and tighten set screw at desired height and lower the other lazy susan shelf over rod onto base piece.
5. Place upper portion of telescoping rod onto lower portion and place upper pivot plate onto upper rod portion. Extend upper rod portion and pivot plate up against cabinet cross member (or final location) and tighten set screw on telescoping rod. Fasten upper pivot plate to cross member.