





Features

- 60° opening angle
- Spiral tech side adjustment for door gap
- Spiral tech depth adjustment for in/out
- Four-dimensional adjustment
- All metal hinge, nickel-plated




Inside corner application 60° use with 155° or 170° hinge on adjacent door

With flat panel doors 60° 11 16 - 21



Bi-fold hinges	Self close
Screw-on	79T8500.10
Press-in 40	79T8530.10

With profile doors frame adapter plate 16 - 21




Calculating door sizes

The doors for a CLIP top bi-fold application can be of equal or unequal width. To calculate the door width (DW) of each door follow the step-by-step below.

- Step 1. Add the interior width to the side panel width (W)
- Step 2. Subtract door thickness (T) and reveal (R)
- Step 3. Subtract gap (G) and bumper thickness behind adjacent door

Formula: DW = (IW + W) minus T minus R minus G

Example: DW = (500 + 19) - 19 - 3 - 1DW = 496 mm



Abbreviations	
DW	= Door width
G	= Gap
Н	= Plate height
IW	= Interior width
R	= Reveal
Т	= Door thickness
W	= Side panel width